




Using the control panel



hp LaserJet 9040/9050mfp

Copy

1. Touch COPY.
2. Touch Describe Original.
3. Touch Page Content.
4. Select Text, Photo, or Mixed.
5. Adjust the options for Density, Sharpness, and Background Removal and then touch OK.
6. Press the START button.

E-mail

1. Place the original on the glass or in the ADF.
2. Touch E-MAIL.
3. If requested, type your user name and password.
4. Complete the remaining fields.
5. Select the settings you want to use by touching Settings and then touching OK, or use the default settings.
6. Press the START button.

Fax

1. Place the original on the glass or in the ADF.
2. Touch FAX.
3. Touch Settings and describe the original.
4. Use the keyboard to type the phone number.
5. Press the START button.

Describes the original document. The HP LaserJet 9040/9050mfp automatically detects the original document size (most sizes).

Use this feature to select the pop-up style "what's this?" help or print step-by-step instructions by using "show me how."

Use this feature to adjust the control panel contrast.

Use this feature to send your document in e-mail.

Use this feature to fax your documents to a standard fax machine. Fax settings and speed dials can also be selected here.

Describes the copied output, including finishing options.

Use these controls to adjust the size and the density of the scanned image.

MENU opens the device menus, including "Retrieve Job."

SLEEP


STATUS shows the current supply status.

STOP cancels a current job.

RESET returns the device to configured defaults.

START

More help




or



Q3726-90959



使用控制面板



hp LaserJet 9040/9050mfp

影印

1. 點選「COPY」(影印)。
2. 點選「Describe Original」(描述原稿)。
3. 點選「Page Content」(頁面內容)。
4. 選取「Text」(文字)、「Photo」(相片)或「Mixed」(混合)。
5. 調整「Density」(濃淡度)、「Sharpness」(清晰度)及「Background Removal」(移除背景)選項，然後點選「OK」(確定)。
6. 按下「START」(開始)按鈕。

電子郵件

1. 將原稿放置在玻璃板上或 ADF 中。
2. 點選「E-MAIL」(電子郵件)。
3. 如果裝置要求您輸入使用者名稱及密碼，請依指示鍵入。
4. 完成其餘欄位。
5. 依次點選「Settings」(設定值)與「OK」(確定)以選取需要的設定值或使用預設值。
6. 按下「START」(開始)按鈕。


傳真

1. 將原稿放置在玻璃板上或 ADF 中。
2. 點選「FAX」(傳真)。
3. 點選「Settings」(設定值)並描述原稿類型。
4. 使用鍵盤鍵入電話號碼。
5. 按下「START」(開始)按鈕。

描述原稿。HP LaserJet 9040/9050mfp 動偵測原稿的尺寸 (絕大多數的尺寸)


使用此功能來選擇快顯式「what's this?」(這是什麼?)說明或使用「show me how」(使用方法)來列印逐步指示。

使用此功能來調整控制面板的對比度。



描述影印的輸出，包括外觀選項。

使用這些控制選項來調整掃描影像的大小及濃淡度。



「MENU」(功能表)可開啟裝置功能表，包括「Retrieve Job」(擷取工作)。

「SLEEP」(睡眠)

「STATUS」(狀態)可顯示目前耗材狀態。

「STOP」(停止)可取消目前工作。

「RESET」(重設)將裝置的狀態回到設定的預設值。

「START」(開始)



使用此功能來以電子郵件傳送文件。


使用此功能將文件傳真到一般傳真機。在此亦可選取傳真設定及快速撥號。



更詳細的說明



或



©2005 Hewlett-Packard Development Company, L.P.

www.hp.com

請參閱使用手冊

請造訪 www.hp.com/support/lj9040mfp
請造訪 www.hp.com/support/lj9050mfp